

GENERAL CARE INSTRUCTIONS

All Granqvists® gloves need to be used according to their designed purpose which is extinguishing fires. In other situations, the product will not guarantee high level of protection which can lead to a compromised product and personal injuries

Storage and transport: keep away from direct sunlight, store in a cool and dry place and keep in original packaging.

Inspection before use: Before every action inspection must be performed in order to check if there is any visible damage.

Never use a damaged product

LEATHER GLOVES



GENTLE WASH AT 40°C, DO NOT BLEACH
DRIP-DRY (OR DRYING CABINET), DO NOT IRON,
DO NOT DRY CLEAN

GENERAL

Use slow and gentle program in 40°C.

DETERGENT (Recommended)

- Ecobright Detergent M

Ecolab AB

Göteborgsvägen 230

125 45 Älvsjö

Phone: +46851989623

Mail Customer service: order.se@ecolab.com

SOFTENER (Recommended)

- Lival Licker KNZ

Tvätt & Textil System AB

Address: Ytterbyvägen 18, 192 76 Sollentuna Phone:

08-626 82 90

WASHING PROCEDURE

1. Put gloves into machine. Note the maximum weight of the machine and calculate that 1 pair weights ca 400gram.

2. Apply Detergent in the tray for main-wash. Usually this is marked with "II". (Recommended dose: 3ml/kg)
- Most important is low alkaline value.
- Example: 2kg of gloves = 6ml detergent

3. Apply softener. (Recommended dose: 15-30ml/kg)

4. Turn the machine on and set to delicate-wash. This program is gentler to the leather thanks to less mechanical abrasion on the gloves. The gloves are cleaned thanks to the detergent and temperature.

DRYING

Dry the gloves in a drying-cabinet 60°C for 240 minutes or in a warm-room over longer time.
DO NOT TUMBLE DRY.

If possible, add some uncoloured leather wax to the gloves after drying. This adds dexterity and water repellence.

TEXTILE GLOVES



GENTLE WASH AT 60°C, DO NOT BLEACH,
DRIP-DRY (OR DRYING CABINET), DO NOT IRON
DO NOT DRY CLEAN

GENERAL

Use similar program as used for fire suits 60°C

DETERGENT

Use common detergents. Avoid bleach and special detergents with high alkalinity intended for e.g. stain removal. We recommend low to medium alkalinity and a pH of < 10.5.

WASHING PROCEDURE

1. Put gloves into machine. Note the maximum weight of the machine and calculate that 1 pair weights ca 300gram.

2. Apply Detergent in the tray for main-wash. Usually this is marked with "II".

3. Washing temperatures should be 60° C/ 140° F, using the 'permanent press' (or similar) setting, and rinse at least twice.

DRYING

Dry the gloves in a drying-cabinet 60°C for 240 minutes or in a warm-room over longer time.